

*Putting your best
skate forward...*

WHIZ TRAINER

CAUTION:


Ensure all screws are tightened before every use.

Ensure child has skate guards on before placing them into the Whiz Trainer.

Keep hands and fingers clear of folding parts.


Ice skating aid with safety harness to protect a child from falling which empowers them and give them confidence when learning to ice skate. This in turn makes learning to skate a fun experience for everyone!

How to use




Step 1

Angle up back section from base




Step 2

Angle up (a little higher than level) the top section




Step 3

Angle up front section from base




Step 4

Line up and push top section couplings over front section pipe



Step 5

Attach front harness strap as shown. Pull tight and tie excess strap in a double knot around tightened strap just above black plastic buckle.



Step 6

Attach rear harness strap as shown. Put two left side straps up through the middle of Whiz Trainer and separate straps by putting one out over back rail and the other across the left side rail and down around the back rail. Connect straps black plastic buckle. Adjust for child's height and tie a double knot with left side straps just above the buckle. Repeat on right side.

The Whiz Trainer is to be used to teach a child to ice skate. This product is to be used only with the supervision of an adult. A child is forbidden to lift another child into the Whiz Trainer. Please view and read written information or visit www.whiztrainer.com/support for instructions on how to use the Whiz Trainer. Please do not use the Whiz Trainer in a household setting or on a floor surface. To be used only on a flat regulated ice skating surface away from any danger.

**Scan to view
How to Use
Video**

